


# SHAD

## EMI ELECTRIC SCOOTER '22 KIT TOP E0LC12IST



1 E0LC12IST-IM x1



2 FOD040 x4  
BUSHING


L32 x Ø10 Ø17mm



3 EOD028 x2  
FLAT WASHER M8



4 EOD041 x2  
BOLT VERSENG  
M8 X L50 DIN 7991



5 EOD019 x2  
HEX BOLT  
M8 X L50 DIN 912



6 EOD049 x2  
FLAT WASHER M10



### ! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

